

Status on Radiation Qualification Methods for SOC Devices

Steven M. Guertin

Jet Propulsion Laboratory / California Institute of Technology Pasadena, CA

This work was performed at the Jet Propulsion Laboratory, California Institute of Technology, Under contract with the National Aeronautics and Space Administration (NASA)

Copyright 2011. All rights reserved.





- Eurotech Adbc7517
 - Freescale P4080 with 8 e500 cores, ~30W, 1.5GHz
 - On-chip XAUI, SGMII, PCIe, RapidIO, SD/MMC, etc... (not all supported by the card)

Outline



- What we're talking about what SOCs?
- Why it's needed?
- What we are trying to do
 - Develop qualification approach
 - Develop test methods
- What work has been done?
- Findings thus far...

Computer Trends




- System on a Chip Trends:
 - Wikipedia: "... System on a chip is hyperbole, indicating technical direction more than reality: increasing chip integration to reduce manufacturing cost and to enable smaller systems."
 - Most microprocessor manufacturers are moving towards multicore devices necessitating on-chip support such as coherency and standard buses
- Space Trends
 - Increasing Fault Tolerance
 - More RHBD offerings, such as Maestro
 - Use of commercial/embedded SOCs in redundant configurations
 - Embrace SOCs due to close ties to embedded market

A couple examples...



- FreescaleMPC8641D
 - P2020
 - P4080
 - **—** ...




A couple examples...



- FreescaleMPC8641D
 - P2020
 - -P4080
 - **—** ...
- Atmel 7913
 - Aeroflex UT699

— ...




A couple examples...



- FreescaleMPC8641D
 - -P2020
 - P4080
 - **—** ...
- Atmel 7913
 - Aeroflex UT699
 - **—** ...
- Boeing Maestro

MAESTRO Chip




National Aeronautics and Space Administration NEPP Interest in SOCs



- SOCs gain popularity and will likely fly soon
 - UT699 is a controller on MISSE-7
 - Several programs interested in flying Maestro
 - SpaceMicro building Proton400k-L with Freescale P2020
- Single Event Effects Test methods unclear
 - Very complex devices
 - Multiple elements do all need to be tested?
 - Hardware simulation of SEEs?
 - Manufacturing processes impact test methods
 - RHBD
 - Fault Tolerance
 - Multicore

National Aeronautics and Space Administration NEPP Approach



- Devices are too complex for full characterization
- Test methods must target basic information needed for manufacturers and provide useful information for users to be aware of and/or mitigate radiation effects
- This approach seeks to provide the information necessary to understand the most important radiation effects for a given system, utilizing manufacturer assistance, and targeting actual application needs.



Quick Word on Rad Effects

- TID
 - Accumulated total ionizing dose to a part
 - Impact can be evaluated by vendor or vendor-specific device parameter test hardware
 - Can be utilize normal reliability flow
- DDD
 - Accumulated displacement damage dose to a part
 - Testing is essentially the same as for TID
- SEE
 - Bit flips, voltage transients, or latchup
 - Testing requires special setup to operate part during exposure
 - Some types of events require observing the device perform the wrong operation
 - Terrestrial testing often requires mechanical modification to test boards and test parts
 - Failure or error modes do not necessarily follow a set of standard part screening methods – may be device specific.

Roadmap to Qualification Methods

- Identify the direction space-borne SOC utilization is going
- Establish requirements for applications
 - Communication with application users
 - Establishing viable test approaches
- Gain understanding of test methods for SEE evaluation of SOCs
 - Through partnerships with SOC manufacturers
 - And direct testing of SOCs to determine what works and what doesn't
- Verify test methods and data by community review with users and manufacturers
- Establish a set of tools to enable qualification methods
 - Application user/manufacturer dialog
 - List of standard interfaces and device architecture elements to target
 - Standardized test approach(es)
 - Box of standard test algorithms for specific internal components
 - Data collection and analysis recommendations
 - Examples of interpretation of results

Target Areas under Development

- Collaboration with Manufacturers and Users
- On-Chip Peripheral Approach/Prioritization
- Fault Tolerant Device Test Approaches
- RHBD Device Challenges to Test Development
- Multicore Device Unique Challenges
- General Test Methods
- Collecting Results from Sample Testing


Collaboration Considerations

- Direct subjects: Aeroflex UT699, Freescale P2020,
 Boeing Maestro, and some others under development
- Working with users to identify most important devices and most important SEE modes: JPL, GSFC, and industry partners
- Test collaborations:
 - User input on key test needs
 - Test collaborators elsewhere in the SEE community
 - Industry test partners are especially needed the current work reflects interaction with Aeroflex, Boeing,
 SpaceMicro, and others



SOCs are Complex Devices

- Built from many sub-units
 - When designing a test approach we must prioritize – what is most likely to be used
 - Each likely unit requires a special approach to test methods
 - Some common structure can be exploited, but requires manufacturer participation



- Developed test approaches
 - Hardware development not feasible have to use demonstration boards
 - Microprocessor approach is the most developed
 - Memory and spacecraft communications are next priority –
 Some SpaceWire methods developed


Fault Tolerant Considerations

- Fault Tolerant Methods:
 - Bit errors: Parity, ECC, Reed-Solomon
 - Device Fail: Reed-Solomon, Redundancy
- What does this mean for testing?
 - Testing these devices usually requires operating the device during testing – test code must handle faults
 - Ground testing is sped up compared to space
 - Requires significantly increased scrub rates
 - Creates test anomalies
 - Temptation to characterize things protected by fault tolerance must be avoided

RHBD Considerations



Example of RHBD device with 3 Mechanisms




- Multi-part SEE sensitivity curve
 - Multiple leading event types at different LETs (see plot)
- Increase in SET sensitivity
 - Dynamic testing more important
 - May require better optimization of test code (to mimic compilers)
 - More detailed clock frequency testing



Multicore Considerations

- Isolation & Error propagation
 - Multiple simultaneous operations
 - Working on ways to orthogonalize problem
 - There are lots of propagation paths – we may have to focus on one device at a time (i.e. Maestro vs. multicore Freescale)
- System-level errors
 - PLL hits
 - Failed Communications or common sub units

MAESTRO Chip





Generalized Test Approach

- Approach must be Multi-stage
 - Realistic assumption, going to require a couple stages to the test approach
- Initial/early-stage approach find out what you got
 - Establish methods to examine if device has big probles
- Establish basic sensitivities
 - Registers, caches, buffers, computation blocks, and modules that can be switched on or off
- Go after key items of the architecture
 - -10
 - Unique coexisting capabilities
- Application sensitivity what the users really need to know
 - /100 or maybe even 1e3-1e4 reduction in application response
 - But may also miss sensitivities in real applications (like Branch History Table)




Testing Update Overview

- UT699 Test Results tested with Aeroflex
 - SRAMs sensitivity,
 - Partial address reset,
 - SpaceWire

- Freescale P2020 efforts tested with SpaceMicro
 - Measurement of basic processor sensitivities

National Aeronautics and Space Administration $Results-UT699\ I\ of\ II$






Original plot: Hafer et. al. 2009 NSREC DW

- UT699 SRAM Sensitivity
- There are 3 different dominant SEU modes
 - Below 20, see next; Between 20 and 60 SRAM SEU;
 Above 60 Flip Flop SEU

National Aeronautics and Space Administration Results — UT699 II of II

- Identified a special upset mode where 16 bits in a register get 0'd out.
- This is likely a SET effect
- We verified the cross section was independent of flux and fluence.
- This is an example of how RHBD devices have difficult SEE modes.



P2020 Testing



- Testing of P2020 in collaboration with SpaceMicro
- SpaceMicro uses the P2020 in their Proton400k-L space computer
- Testing was performed with a P2020RDB from Freescale





NEPP SOC Update for ETW 6/29/2011

National Aeronautics and Space Administration $Results - P2020\ I\ of\ II$



- P2020 tested for SEUs using 55 MeV protons at UCB
 - Cores tested for L1, L2, and GPR sensitivity
 - L2 (4194304 bits tested as SRAM):
 - ECC disabled
 - 10079 upsets in 2.36e11 protons/cm²
 - Yields cross section of 1.0e-14 cm²/bit
 - L1 (about 278528 bits due to tags and invalidations)
 - · Parity exceptions/checking disabled
 - No SBU seen until MBU, but disproportionately high invalid lines
 - We assume lines being invalidated by parity checking
 - 779 invalid lines in 2.36e11 protons/cm²
 - Yields cross section of 1.2e-14 cm²/bit
 - GPRs (704 bits)
 - 1 upset in 2.36e11 protons/cm²
 - Yields cross section of 0.6e-14 cm²/bit
- Only tested P2020 processor core thus far other test targets are:
 - Multi-processor coherency module
 - On-chip peripherals, especially: Ethernet, PCIe, MMU, Serial Rapid I/O, (SERDES)

#1: All tested elements have cross section about 1e-14cm²/bit @55MeV protons #2: Basic microprocessor items tested = still need to do peripherals and coherence₂₃


National Aeronautics

and Space Administration Results -P2020 II of II



- Comparing 45nm P2020 results...
 - plotted with IBM750FX - 90nm
 - similar to e600based Freescale parts (7448, 7447A)
 - Protons only... still need to do heavy ion testing
- Also looking at other Freescale multicore
 - Looking at P4080 and MPC8641D

Cache Proton Sensitivity



Future Directions



- Continue collaboration building especially on the user side.
 - Building goals based on desired data for users
 - But also need manufacturer support for correct sensitization and to provide input on what users desire to be hardened
 - Especially looking to orthogonalize the problem of error/fault propagation in complex multicore devices
- Continue improvement of test methods targeting the key areas discussed
 - Key peripherals, Fault Tolerance, RHBD elements, specific Multicore concerns
 - And overall improvement of generalized test approach to provide a roadmap for efficient device SEE research
- Immediate development targets
 - Freescale multicore devices, from P2020 to P4080
 - Others in our sites but not active: Maestro, Atmel AT7913, Aeroflex LEON 4
 - If you have other specific devices of interest, please contact <u>steven.m.guertin@jpl.nasa.gov</u> to discuss potential options
- Recommendations for SOC SEE test methods
 - Expect to develop this work into a general guideline for SEE evaluation and testing of complex SOCs

Summary – I of II



- SOCs are becoming more common and are expected to impact NASA soon
 - SOC here generally means devices complex devices carrying out multiple roles (rather than carrying out ALL roles)
 - Some are already flying or in planning stages
- NEPP approach is to try to close the loop between vendors, users, and radiation testers
 - Basic test data is needed,
 - But certain types of questions may require special test approaches (such as fault propagation)
 - Users may be unaware of how SEE testing maps to application sensitivity.
 - Many test types would benefit from manufacturer involvement, and some cannot be done without it.

Summary II of II



- Currently targeting 7 areas for development
 - Collaboration
 - Prioritizing device resources for evaluation
 - Approaches for Fault Tolerant element testing
 - Approaches for RHBD device testing
 - Multicore challenges
 - General test methods for SEE testing
 - Field validation by testing devices of interest
- Current or past testing targets
 - Aeroflex UT699 found rare partial register reset (below 1 in 1e5 years in GEO), found very low SpaceWire upset rate
 - Boeing Maestro Worked on methods for testing including identification of manufacturer functional test codes recommended for SEE testing, NEPP efforts on hold
 - Freescale P2020 and other devices working on initial verification of test methods. Eventually plan to establish and demonstrate test methods on at least one of Freescale device.